6. Trouble shooting guide

6.1 Needle on right side of scale, buzzer sounds and led flashes.	Sender cable blue/black disconnected.
6.2 Trimindicator functions properly but buzzer sounds and led flashes.	First check oil- and water- temperature sender. Alternately pull connectors from senders. If buzzer stops respective sender is defective. If not proceed to point 6.5.
6.3 Needle is down and does not move during trimming.	Trimsender unit or instrument sender connection grounded or trim indicator defective.
6.4 Only during starting led flashes and buzzer sounds, otherwise everything ok.	Electronics in instrument too sensitive.
6.5 Instrument (also water- and oil- temperature) responds to the use of light switch.	No ground connection to instrument.

V12 Engineering
Box 50, Ontario, Canada P0X 1C0
www.bmwmarine.net